


```
1
                  Cabinet (Not A Serviceable Part)
2
      2189410
                 Hinge (Top)
                 Roller-Front (2)
3
      2166108
                 Clamp, Tube (Water Supply Line)
      489385
5
     2179826
10
                 Rivet
11
     2174650
                  Screw
12
     549193
                 Clamp-Cord
15
     489497
                 Screw
16
      2183972
                 Hinge, Center
17
      2183854
                  Shim, Hinge Center
                  Screw
18
     489464
20
     2189194
                 Hinge Butt
23
     2172743
                  Shim, Bottom Hinge
24
                  Fitting, Water Tube (Not Serviced)
27
     2201012
                 Hole Plug (6)
                 Cover, Valve
      2166251
31
35
      2201014
                 Corner Filler (2)
36
     2183991
                 Grille
37
     489341
                 Washer
38
     487576
                  Washer
40
     2160403
                 Cover-Hinge
41
                  Rail, Center (Not Serviced)
42
      2166156
                  Corner Filler, Grille
44
      2189060
                 Cover, Unit
```


DOOR PARTS For Models: 7ET21PKXGW00 (White) -13 22-Ø Ø Ø 27 17、

```
1
                  Refrigerator Door (Includes #9 & #22)
      2183920
2
                  Handle, Trim
      2193553W
5
      2193351W
                  Handle Center
6
      489357
                  Screw
8
      487909
                  Screw
9
                  Door Gasket, Magnetic
      2159061
                  Mist Beige
13
      2175383
                  Nameplate
      2195378
                  Trim, Door Shelf
16
17
      489028
                  Screw
19
      2182489
                  Freezer Door (Includes #22 & #23)
20
      2189000
                  Hole Plug
21
      2159304
                  Shelf, Flip-Up
22
      2183003
                  Thimble
23
                  Door Gasket, Magnetic
      2159060
                  Mist Beige
25
      2195395
                  Bin, Door Shelf
26
      2189202
                  Bracket, Door Stop (2)
27
      488921
                  Screw
28
      844478
                  Hole Plug
29
                  Plug-Trim
      2156007
                  Plug-Trim
30
      2156006
      2177130
                  Compartment Door
31
33
      2193350W
                  Handle, F.C.
37
      2195947
                  Trim-Door (2)
                  Endcap (4)
41
      2195916
42
      2195948
                  Trim, Door
      2199047
                  FeaturePak (Includes 16, 25, 29, 30, 31, 37, 41, 42) Also See
100
Shelf Parts Page.
```



```
1
                  Liner (Not A Serviceable Part)
2
      531933
                  Grommet (2)
3
      2184634
                  Gasket, Evaporator Cover (Side)
4
     2193084
                  Timer, Defrost
5
     549512
                 Thermostat Tube Barrier
6
     941839
                 Hole Plug
7
     2193493
                 Wire Assy. Control Box
8
     2162085
                  Socket, Light (2)
                 Damper, Air
9
      2179858
10
     2183448
                  Fan Motor
11
     2163777
                 Fan Blade
12
     2179790
                  Control Box
13
     2197536
                  Thermostat Assy. (Includes Items 5, 18 & 36)
14
     489478
                  Screw
15
     489412
                  Screw
     2189823
                  Cover-Evaporator
16
17
     527949
                 Light Bulb (2)
18
     2163802
                  Weight, Thermal
19
     1118894
                  Switch, Rocker Arm
20
     2179859
                  Post, Damper
                 Cover, Air Diffuser
21
     2176281
                  Knob, Thermostat
22
     2193455
                  Air Tower
23
     2182340
                 Air Diffuser, Bottom
24
     2176280
25
                 Freezer Floor
     2184617
2.6
     2179877
                  Air Diffuser, Top
27
     2190688
                  Cover, Hole
     2198901
29
                  Bracket, Fan Motor
30
                  Gasket, Evaporator Cover (Top)
     2184635
31
      2174629
                  Air Return & Foil Assembly
32
     487996
                  Cap
33
                 Clip, Defrost Timer
     2176341
34
     2176297
                  Knob, Damper
35
     2163810
                  Bracket, Damper Knob
36
     2172532
                  Seal, Rear Thermostat
                  Valve, Release
38
     2171931
                  Wire Assembly, Freezer Compartment
39
      2195656
```

UNIT PARTS



```
1
      2195272
                  Plate, Unit Mounting
2
      489478
                  Screw
3
      2195400
                  Condenser
4
      2166124
                  Heater, Defrost
5
     2195390
                  Evaporator Assy.
6
      489499
                  Screw
7
      2172620
                  Drain Pan
8
     2182380
                  Defrost Bi-Metal
                  Bracket, Heater
9
      2176301
10
      2163780
                  Extension, Air Baffle
11
      943322
                  Cover, Strap
12
     1105055
                  Cover
13
                  Overload
      2154759
                  Service (Includes Relay)
      2183409
                  Production (Includes Relay)
                  Grommet (4)
14
      2183042
                  Production
      1100826
                  Service
15
                  Relay (See Overload)
16
      2189906
                  Support Block
17
      836054
                  Roller (2)
18
      981126
                  Rivet
                  Clip, Heater
19
      2182338
      489473
20
                  Screw
2.3
      2198740
                  Cover, Unit
                  Compressor (Includes Items 12, 13, 15, 29, 32, 38 & 56) (Also
28
      2183439
Order)
                  Installation Kit &
      482801
                  Tube Kit
      876765
29
      2174865
                  Drier
30
      2155774
                  Clamp
38
      2172890
                  Wire Assembly
39
      2198921
                  Air Baffle
40
      2183437
                  Motor, Condenser
42
     2189997
                  Wire Assy. Unit
                  Fan Blade
43
      2190685
44
      486692
                  Nut
      2184451
                  Tube, Discharge
46
47
      2189173
                  Tube, Suction
                  Tube, Process
48
      2154109
49
      2174670
                  Tube, Condenser To Heat Loop
57
      489462
                  Screw
58
      2176276
                  Tray, Evaporator
Following Parts Not Illustrated and Optional Parts Not Included
      978025
                  Valve, Access (1/4")
      978026
                  Valve, Access (5/16")
      978027
                  Valve, Access (3/8")
                  Valve, Access (1/2")
      978028
                  Valve, Access (5/8")
      978029
      978030
                  Valve, Access (3/4")
      876764
                  Valve, Access (3/16")
      482278
                  Start Kit
```

REFRIGERANT CHARGE 4.0 Ozs. (R134A)

SHELF PARTS For Models: 7ET21PKXGW00 (White) 17、 18 ---19

```
1
      2163756
                  Shelf, Ladder (2)
                  Shelf, Ladder Center
2
      2163826
3
      2163762
                  Cup, Shelf Mtg.
4
     2189314
                  Screw Support
5
     489415
                 Screw
6
     2182730
                 Egg Bin
                 Glass, Full Shelf
7
     2199192
8
     2199185
                 Trim, Shelf Rear
9
      2195344
                  Crisper Cover
10
      2163860
                  Shelf, Cantilever
11
     2176225
                  Insert, Crisper Cover
12
     2176306
                  Pan, Shelf Cantilever
13
     2199191
                  Glass, Shelf
14
     2199178
                 Trim, Shelf Front
15
                 Crisper Support
     2163832
                  Shelf, Full Cantilever
16
      2199195
17
                  Shelf, Freezer
      2184667
18
     2199183
                  Trim, Shelf Rear
19
                 Trim, Shelf Front
     2199180
20
     2195403
                 Pan, Meat
21
     2199188
                  Trim, Shelf Side
22
                  Ice Tray (2)
      841180
24
      2190601
                  Crisper Pan
                  FeaturePak (Includes 6, 10, 12 13, 14, 18, 19, 20, 21, 23, 25)
100
      2199047
Also See Door Page.
Parts Not Illustrated and Optional Parts (Not Included)
Miscellaneous
      978941
                  Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
      212643
                  Sealer, Gum (4 Feet)
                  Tape, Vinyl (3/4" \times 108")
      479502
      876305
                  Kit, Insulation (14 Pcs. 3" \times 24" \times 48")
      876370
                  Kit, Insulation (2 Pcs. 3" x 24 " x 48")
      876029
                  Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
                  Sealer, Mastic (1 Qt.)
      505587
      511873
                  Touch-Up, White Porcelain (2 Oz.)
                 Grease, Silicone (1/2 Oz.)
      542638
      542639
                 Cement, Alumilastic (1-1/4 Oz.)
      606755
                  Bag, Insulation (36-5/8" x 46")
                 Kit, Evaporator Repair (Aluminum Epoxy)
      799833
      799832
                  Kit, Porcelain Repair (White)
      503695
                  Cork Sealer (1/4 Pound)
      2172516
                  Door Reversal Instructions
Customer Touch-Up Material
      350942
                  *Primer, White (13 Oz. Spray Can)
      350939
                  *Enamel, Black (13 Oz. Spray Can)
                  *Enamel, White (13 Oz. Spray Can)
      350930
                  *Enamel, Almond (13 Oz. Spray Can)
      350956
      72017
                  Brush Touch-Up Kit (White)
      72032
                  Brush Touch-Up Kit (Black)
      72107
                  Brush Touch-Up Kit (Almond)
Refinishing Material
      799344
                 Enamel, White (1 Qt. Uncut)
                 Enamel, Almond (1 Qt. Uncut)
      978883
```

833938 Kit, Terminal Connector

*Caution: The Spray Paint Is Not To Be Used Where The Paint May Make Contact With The Door Gaskets

LITERATURE PARTS

LIT2195481 Service & Wiring Sheet

LIT2200755 Energy Label

LIT2200595 Use & Care Guide

Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS

LIT677969 Do-It-Yourself Manual Ref./Fzr. LIT677971 Do-It-Yourself Manual, Icemaker

FIELD INSTALLABLE ICE MAKER ECKMF94

TORX SCREW WRENCH

1117510 Torx Key